EKASTU | Safety WIR PRODUZIEREN SICHERHEIT!

Technical Data Sheet

EKASTU-Eye Wash Unit Aqua Push



Order no.: 177 500 EAN: 4013207177501

Product designation:

EKASTU-Eye Wash Unit Aqua Push

The EKASTU-Eye Wash Unit Aqua Push is manufactured according to factory specifications and complies with DIN EN 15154-2 and the BGI/GUV-I 850-0 "Safe working in laboratories - principles and guidelines" issued by the German Social Accident Insurance (DGUV).

Eye showers with a water connection are mandatory first aid equipment for workplaces where hazardous substances are handled. The eye shower is used for targeted rinsing of the eyes and for rinsing the face



DESCRIPTION

- The EKASTU-Eye Wash Unit Aqua Push is ideal for quick and effective irrigation as part of first aid treatment after an eye accident
 Specially, ergonomically shaped shower head, made of high-quality medical material, which gently surrounds the eye to be rinsed and prevents the eyelid closure reflex
- Aqua Push delivers a wide and even iet of water (approx. 7.2 l/min)
- Easy-to-use handle made of robust plastic, with the option of locking, for even more comfortable rinsing of the contaminated eve
- Dust cover protects the eye shower from contamination
- · Easy commissioning thanks to simple connection to the local cold/drinking water pipe
- Includes easy-to-clean, flexible shower hose with kink protection and standardized 1/2 inch (ISO 228) connection
- · Ideal for wall mounting, wall bracket included in the scope of delivery
- · Suited ideally for a wide range of areas, such as industry, laboratories, universities and schools
- · Self-adhesive sign for standard-compliant labeling of the eye wash unit

MAIN FEATURES



MATERIALS

The materials used are particularly kind of the skin and therefore have no negative effect on human health

- Handle:
- Shower head:
- Dust cover:
- Wall mounting:
- Shower hose:

High-density polyethylene (HDPE) Low-density polyethylene (LDPE) Acrylonitrile-Butadiene-Styrene (ABS) Polyvinyl chloride (PVC)

High-density polyethylene (HDPE)

WEIGHT

• approx. 400 g

MARKING

• Trade mark of manufacturer (EKASTU Safety)

DONNING AND USING

• Store the EKASTU-Eye Wash Unit Aqua Push and spare parts in a dry place, protected from dust and corrosive and oxidant agents

HANDLING

- The eye shower should be connected to a cold drinking water connection.
- The location of the eye shower must be known to all employees

• Please consider the information brochure!

USER REFERENCES

EKASTU Safety GmbH guarantees the indicated achievement according to class and type. It is to be noted that the laboratory test values can considerably deviate from those, which are reached in practice. The user must read and understand all functional information. Use the EKASTU-Eye Wash Unit Aqua Push with this information brochure, the relevant valid statutory regulations and the safety requirements of the profession associations for example DGUV Information 204-022 "First Aid in Operation".

TD 177 500 English_01-07.25

EKASTU Safety GmbH Schänzle 8 • D-71332 Waiblingen Germany

Tel.: +49(0)7151 975099-0 Fax: +49(0)7151 975099-30 Internet:www.ekastu.de eMail: info@ekastu.de